



NOTE :- RV1 SETTING, MEASURE SUPPLY RAIL VOLTAGE BETWEEN PINS 1+5 ON IC14
 MEASURE BETWEEN POSITIVE END OF C60 AND PIN 5 ON IC14. ADJUST RV1 TO HALF
 SUPPLY RAIL +/- 250mV